

COMFAST

**Outdoor AP
Quick Installation Guide**




Outdoor AP
M0304491 Version 2.0

1. Cable installation diagram



- ③ Put the network cable in the hole under the cover Top cover
- ② Connect the network cable to Device LAN/WAN port
- ① Remove the face cover

2. Device connection diagram



3. Set the computer to obtain the IP address automatically, and connect the LAN port of the device to the computer to enter the management page.


4. The device is defaulted to the interface Repeater mode. The steps to enter the setup page as follows:

(1) Under default configuration, power on the device and wait for the device to start for 90 seconds.


(2) Connect device wireless SSID (default is COMFAST_EW75).

(3) Open the computer browser, and input 192.168.10.1 to get into the device login page (Default password:admin).

The device language is compatible with Chinese and English to choose, and you can set up the language by the top right corner icon 🌐



5. When getting into the setting page, there are four working modes in the Wizard: AP Mode, Bridge Mode, Router Mode, Repeater Mode.



6. Click AP mode and set up IP Address and Subnet Mask. The IP address and Subnet mask should be within the same network segment as upper network and can't be conflict with IP address from upper network router. After settings, you can visit the device from the IP address you have set just now by connecting internet with WAN port of the device or POE adaper LAN port.

① Note: In AP mode, the IP address from the other devices connected the AP will be allocated by the upper network router.

②The AP needs to set an intranet IP address (do not set the same IP address as the upper router). If want to manage the device, Manually set the IP address of the same network segment of the intranet IP.

① Lan Settings ② Wireless ③ Finish

Lan Settings

IP Address

Subnet Mask

Next

7. AP Mode: You can set up 2.4G/5.8G wireless SSID, password, channel and country in advance. After setting up, the device's WAN port or POE adapter LAN port connected internet, other mobile devices can connect the SSID to surf the internet. (Note: The SSID in WIFI Unification supports 2.4G and 5.8G simultaneous connection)

① Lan Settings ② Wireless ③ Finish

WIFI Unification ON

Wireless

SSID

Password

Country

24G Bandwidth

24G Channel

58G Bandwidth

58G Channel

Prev Next

8. Bridge Mode: The AP device can set the intranet IP, select the wireless SSID signal that you need to bridge (distinguish between 5.8GHz and 2.4GHz), and enter the password.

① Note: In Bridge mode, the access to the external network, the network segment of the IP address obtained by other mobile devices accessing the AP is assigned by the superior.

② According to the default setting, you can also set the device-specific intranet IP address. If you need to manage the device, you must manually set the IP address of the computer's locally connected network card.

(1) LAN network IP setting(This IP address can as the management IP).

① Lan Settings ② Bridge Settings ③ Wireless ✓ Finish

Lan Settings

IP Address

Subnet Mask

Next

(2) Click scan, search and select the wireless SSID that you want to bridge, and enter the wireless password.

① Lan Settings ② Bridge Settings ③ Wireless ✓ Finish

Bridge Settings

Scan Band

SSID Scan

Password

Prev Next

(3) Set the SSID and password of the 2.4G/5.8G of the AP (Wifi Unification mode: 2.4G and 5.8G use the same SSID and password)

Note: Turn off WiFi Unification. You can set the SSID and password of 2G/5G separately.

① Lan Settings ② Bridge Settings ③ Wireless ④ Finish

WIFI Unification ON

Wireless

SSID

Password

Prev

9. Router Mode: There are three ways to surf the internet: PPPOE, Static, and DHCP. (PIs refer to router setting as reference)

Note: In Router mode, if you need to manage the device, you need to connect to WIFI to enter the management page.

① WAN Settings ② Lan Settings ③ Wireless ④ Finish

WAN Settings

PPPoE Static DHCP

IP Address

Subnet Mask

Gateway

DNS

10. Repeater Mode: You can set the LAN network IP of the AP. Then, select the wireless SSID that you need to repeat (distinguish between 5.8GHz and 2.4GHz), and enter the password of the wireless network.

① Note: In the repeater mode, the IP address of other mobile devices accessing the AP are assigned by the device.

(1) LAN network IP setting.

① Lan Settings ② Repeater Settings ③ Wireless ④ Finish

Lan Settings

IP Address

Subnet Mask

Next

(2) Search for the wireless SSID you want to repeat, then enter the wireless password.

① Lan Settings ② Repeater Settings ③ Wireless ④ Finish

Repeater Settings

Scan Band

SSID Scan

Password

Prev Next

(3) Set the SSID and password of the 2.4G/5.8G of the AP (Wifi Unification mode: 2.4G and 5.8G use the same SSID and password)

Note: Turn off WiFi Unification. You can set the SSID and password of 2G/5G separately.

① Lan Settings ② Repeater Settings ③ Wireless Finish

WIFI Unification ON

Wireless

SSID

Password

Prev

Quick Installation Guide

Statement

**Shenzhen Four Seas Global Link Network
Technology CO.,Ltd.Company
all rights reserved.**

Without our official written permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means (electronic, mechanical, printing, recording or other possible means) or for the propagation of goods for any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co., Ltd. Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreements, this manual is used only as a user guide. All statements, information, etc. do not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network
Technology Co., Ltd. Company
Address: Room 607-610, Block B Tao JINDI Electronic
Business Incubation Base, Tenglong Road, Longhua District,
Shenzhen, China
Hotline: +86 755 83790059
Website: www.szcomfast.com