



Quick Installation Guide




Wireless Router
M0304466 Version 5.0
.0

1 Connection Diagram


1.1 If use dial-up internet, pls follow up below connection steps

1.2.3.4; If use broadband internet, pls follow up below connection steps 2.3.4 and connect WAN port of wireless router to internet directly.

Dial-up Internet



Broadband Internet



Wireless Connection

Scan wireless signal and the SSID is
COMFAST_MAC last 6 numbers/
COMFAST_MAC last 4 numbers_2G/
COMFAST_MAC last 4 numbers_5G



Power Socket



Wireless Router


4 Power Port



2 Connect WAN Port

3 Connect LAN Port


Wired Connection



Attention: This user manual is only for settings steps. If have more function requirements, pls visit our web: www.szcomfast.com

2 Setting Steps

2.1 After connection step finished, input 192.168.10.1 in your browser and get into the setting interface. Input user name and password. (User Name: admin Password: admin)



The screenshot shows the login page for a COMFAST device. At the top center is the COMFAST logo. Below it are two input fields. The first field is labeled 'User name' and has a person icon to its left. The second field is labeled 'Password' and has a key icon to its left. Below these fields is a dark grey button with the word 'LOGIN' in white capital letters.

2.2 Select "SETUP WIZARD" for Routing mode settings. In WAN settings, pls enter account number and password and set "up" and "down" .

Attention: If login at the first time, it will go to "SETUP Wizard" automatically. It is same if reset to factory settings.

1 WAN settings — 2 LAN settings — 3 2.4GHz settings — 4 Done

WAN settings

ADSL/PPPOE Static IP Dynamic IP

User name:

Password:

Service Provider:

Up:

Down:

Back **Next**

2.3 In LAN settings, pls input IP address and Subnet Mask.

Attention: It is usually as defaulted settings.

1 WAN settings — 2 LAN settings — 3 2.4GHz settings — 4 Done

Network Settings


IP Address:

Subnet Mask:


Back **Next**

2.4. In 2.4GHz settings, pls input SSID and password. (It is same way if it is 5.8GHz signal)

Attention: SSID is WiFi signal name and password is the wifi password. (Password requires alphabet and numbers together)



2.5 Click " Done " to finish the settings. Then the interface will go to the home page; The device status will can be checked if log in again.



Warnings

1. Pls take off all connection if lightning weather in order to protect the device from damage.
2. Pls stay away from the heat source and keep ventilated.
3. Pls stay away from water when storage, transportation or working.
4. Pls use the power source which standard in the packing.
5. Pls put the device in a smooth surface.

3 FAQ

1. If I forget the login name and password of the device, what should I do(how to reset the router)?

A. If you forget the login name and password of the device, the only way you can do is do factory reset to the device, then the login name and password will be restored to their default values. At the bottom of the device there is a Reset button, when power is on, press and hold the button for 10 seconds, after the indicator LED has blinked 3 times rapidly, release the button and finished the Reset operation.

2. What if i can't open the administrator page of device in browser?

A. Please make sure the ip address of your computer is in the same network segment as the IP address of the device administrator page you typed in browser: for example, if your device default login IP address is 192.168.10.1, then the IP address of your computer should have been 192.168.10.x(x is any integer between 2 and 254):

B. Please make sure your browser setting is "Never dial a connection" and disable proxy; Here is the steps of configuration (suppose you use IE): Click "Tools"->"Internet Options"->"Connections", choose "Never dial a connection"; Click "Lan settings", remove the option of "Proxy server".

C. Try change another computer to log in: If all the 3 hints above can't help you, please do the Factory Reset Operation to the device and log in again.

3. Why my laptop can't search out the signal of Wi-Fi SSID?

A. If your laptop has network adapter built-in, please make sure the Wi-Fi function is enabled(we recommend you connect the laptop vendor or read the laptop user manual);

B. At device manager interface, check whether the driver of network adapter has been installed successfully;

C. Check whether the wifi service has been turned on, right click the icon "my computer" on your desktop, choose manage. In "Computer Management" wizard, click "Services and Applications", then on the page of "Service", find the item "Wireless Zero Configuration" and check its Status value.

D. Please make sure you've enabled the wifi capability and enabled SSID broadcast.

E. Get closer to the router and try search again, Avoid the factor of obstacles which reduce the intensity of signal; If the hints above can't help you, please check out whether another wireless network adapter can connected to the router. If it still don't work, please do the factory reset operation to restore the parameters back to their default values.

Quick Installation Guide

Statement

**Shenzhen Four Seas Global Link Network
Technology CO.,Ltd.Company
all rights reserved.**

Without our official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network
Technology Co.,Ltd.Company
Address: Room 607-610,Block B Tao JINDI Electronic
Business Incubation Base, Tenglong Road, Longhua District,
Shenzhen, China
Hotline: 0755 83790059/83790659
Website: www.szcomfast.com